# Waterproof 4 Channel Constant Voltage Power Repeater

# Model No.: EV4-WPS

IP67 waterproof/4 Channel/PWM signal input/Constant voltage output/3KV optoelectronic isolation

## **Features**

- Waterproof 12-36V constant voltage power repeater with IP67 rating, suitable for outdoor and damp environment.
- 4 channel, 5A per channel.
- To receive PWM signal control.
- Power repeater in series or in parallel to expand output unlimitedly.
- Apply to single color, dual color, RGB or RGBW constant voltage LED strip or module.



C€ RoHS emc LVD


### **Technical Parameters**


Input and Output	
Input voltage	12-36VDC
Input current	20.5A
Input signal	PVVM
Output voltage	4 x (12-36)VDC
Output current	4CH,5A/CH
Output power	4 x (60-180)VV
Output type	Constant voltage

Safety and EMC		
ETSI EN 301 489-1 V2.2.3		
ETSI EN 301 489-17 V3.2.4		
EN 62368-1:2020+A11:2020		
ETSI EN 300 328 V2.2.2		
CE,EMC,IVD		
Package		
L165 x W98 x H72mm		
0.492kg		

Warranty and Protection		
Warranty	5 years	
Protection	Reverse Polarity Over-heat Over-load Short circuit	
Environment		
Operation temperature	Ta: -30 °C ~ +55 °C	
Case temperature (Max.)	T c:+75°C	
IP rating	IP67	


#### Mechanical Structures and Installations






## Wiring Diagram

## • Parallel connection



User Manual Ver 1.0.0



# Malfunctions analysis & troubleshooting

Malfunctions	Causes	Troubleshooting
No light	No power.     Wrong connection or insecure.	Check the power.     Check the connection.
Wrong color	1. Wrong connection of R/G/B/W wires.	1. Reconnect R/G/B/W wires.
Uneven intensity between front and rear,with voltage drop	Output cable is too long.     Wire diameter is too small.     Overload beyond power supply capability.     Overload beyond controller capability.	<ol> <li>Reduce cable or loop supply.</li> <li>Change wider wire.</li> <li>Replace higher power supply.</li> <li>Add power repeater.</li> </ol>

# Safety & Warnings

- 1. The product shall be installed and serviced by a qualified person.
- 2. Good heat dissipation will prolong the working life of the controller, Please ensure good ventilation.
- 3. Please check if the output voltage of any power supplies used comply with the working voltage of the product.
- 4. Ensure all wire connections and polarities are correct and secure before applying power to avoid any damages to the LED lights.
- 5. If a fault occurs please return the product to your supplier. Do not attempt to fix this product by yourself.

User Manual Ver 1.0.0