

Touch Glass Panel 0/1-10V Dimmer

- Touch panel 0/1-10V dimmer, output 1 channel 0/1-10V signal.
- Output connect with 0/1-10V dimmable driver.
- High voltage AC input, high voltage AC relay output, with zero-crossing detection.
- Ultra sensitive high strength glass touch panel with touch slide in the middle.
- Compatibility with RF 2.4G dimming remote control.
- Touch keys with LED indicator.
- High-inrush specification relay.
- White & Black glass panel available.



Gross weight

0.238kg

Technical Parameters

Input and Output

Input voltage

Output signal

Output current

Environment


IP rating

Relay surge current

Dimming data Safety and EMC ETSI EN 301 489-1 V2.2.3 ETSI EN 301 489-17 V3.2.4 AC100-240V Input signal Touch key + RF 2.4GHz EMC standard 0-10V (50mA) RF control distance 10m(Barrier-free space) EN 61347-1:2015+A1:2021 EN 61347-2-13:2014+A1:2017 Safety standard Dimming gray level Max. 3A (AC) 256 levels 200A Dimming range 0-100% Radio Equipment ETSI EN 300 328 V2.2.2 Certification CE RED Ta: -30°C ~ +55℃ Package Warranty Operation temperature Case temperature (Max.) Tc: +65 °C Warranty 5 years Size L112 x W112 x H50mm


Mechanical Structures and Installations

IP20




Wiring Diagram

• Connect with 0/1-10V dimmable driver (no use AC OUT)



• Connect with 0/1-10V dimmable driver (use AC OUT)




Note:

- 1. We recommend the number of LED drivers connected to 0/1-10V dimmer does not exceed 100 pieces,
- 2. The MAX. surge current of the AC OUT is 200A. When connecting multiple capacitive (LED power supplies) or inductive loads, the sum of the surge currents can not exceed its maximum value. Otherwise, long-term use may cause product damage.

0-10V or 1-10V Dimming Setting

Select 0-10V dimmer or 1-10V dimmer according to dimmable LED driver.



Match Remote Control (Two Match Ways)

The O-10V touch panel dimmer can also match with the RF dimming remote (optional). End user can choose the suitable match/delete ways. Two options are offered for selection:

Use On/Off key

Match:

Turn on light, turn off, immediately press the On/Off key of the panel for 5s, then press on/off key (single zone remote) or zone key (multiple zone remote) of the RF remote within 5s.

The LED indicator fast flash 3 times means match is successful.

Delete:

Turn on light, turn off, immediately press the On/Off key of the panel for 10s to delete all match,

The LED indicator fast flash 6 times means all matched remotes were deleted.

Use Power Restart

Match:

Switch off the power, then switch on power, repeat again, Immediately short press on/off key (single zone remote) or zone key (multiple zone remote) 3 times on the remote. The LED indicator blinks 3 times means match is successful.

Delete:

Switch off the power, then switch on power, repeat again, Immediately short press on/off key (single zone remote) or zone key (multiple zone remote) 5 times on the remote. The LED indicator blinks 5 times means all matched remotes were deleted.